

Manual, Assembly instruction: Brodit 855445

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Gently pull the front frame/panel around the instruments out a little. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.
2. Hook the left J shaped edge on the left part of the ProClip over frame surrounding the buttons. This ProClip can be placed to the right of either the upper or the lower buttons.
3. Press the front frame/panel around the instruments back into place. Hook the right edge of the ProClip over the edge of the frame/panel around the instruments.
4. The ProClip is in place.