

Manual, Assembly instruction: Brodit 855448

Center mount ONLY for models with 7" display.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the thin edge on the lower part of the ProClip over the frame surrounding the air vent.

2. Press the upper part of the ProClip downward/forward and hook the grooved edge under the edge of the frame surrounding the air vent. 3. The ProClip mount is in place.

4. The ProClip mount is in place.