

Manual, Assembly instruction: Brodit 855454

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the silver trim, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.

2. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener.

3. Press the upper part of the ProClip downward and forward. Hook the angled edge on the upper part of the ProClip under the frame surrounding the air vent. Pull out the gap opener.

4. The ProClip is in place. This ProClip can be placed anywhere within the width of the air vents. If placed onto the left air vent, a device installed in this position may block the display.