

Manual, Assembly instruction: Brodit 855456

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place/hook the notched edge on the right part of the ProClip over onto the inner edge of the frame surrounding the air vent.

2. Press the ProClip to the right and forward. Hook the notched edge on the left part of the ProClip onto the inner edge of the frame surrounding the air vent.

3. The ProClip mount is in place.

4. The ProClip mount is in place.