

Manual, Assembly instruction: Brodit 855460

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Adjust the air vent downwards. Press the angled edge on the lower part of the ProClip into the gap between the air vent and the dashboard.
2. Press the upper part of the ProClip downward/forward and hook the angled edge into the gap between the air vent and the dashboard.
3. This ProClip can also be placed on the right air vent.
4. The ProClip is in place.