

## Manual, Assembly instruction: Brodit 855462

Center mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the lower edge of the ProClip into the frame surrounding the air vent, so the adhesive tape attaches.
2. Press the ProClip downward and forward, and hook the angled upper edge under the frame surrounding the air vent.
3. This ProClip can be placed anywhere within the width of the air vent.
4. The ProClip is in place.