

Manual, Assembly instruction: Brodit 855464

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the top of the ProClip under the frame surrounding the air vent so the tab rests on the frame.
2. Press the ProClip upward and forward. Hook the grooved edge on the lower part of the ProClip over the frame surrounding the display.
3. This ProClip can be placed anywhere within the width of the air vents.
4. The ProClip is in place.