

Manual, Assembly instruction: Brodit 855467

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin edge on the lower part of the ProClip into the gap between the center panel and the thin frame surrounding the air vent (not the gap closest to the air vent).
2. Press the upper part of the ProClip downward and hook the notched edge onto the frame surrounding the air vent.
3. The ProClip can be placed anywhere within the width of the air vents.
4. The ProClip is in place.