

Manual, Assembly instruction: Brodit 855469

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the chrome console trim and the inner center console panel, to widen the gap. Peel off the adhesive tape cover on the ProClip.

2. Press the thin left edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the chrome console trim and the outer center console panel. Press the ProClip to the right and insert the thin right edge of the ProClip into the gap next to the gap opener. Pull out the gap opener. 4. The ProClip is in place.