

Manual, Assembly instruction: Brodit 855472

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the panel above the instrument panel and the surrounding frame, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip
2. Press the thin right edge of the ProClip into the gap next to the gap opener.
3. Press forward on the left side of the ProClip so the left edge hooks into the gap between the panel and the glass. Pull out the gap opener.
4. The ProClip is in place.