

Manual, Assembly instruction: Brodit 855478

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the left edge of the ProClip into the gap between the inside side wall of the center console, and the dashboard.

2. Press downward on the right side of the ProClip. At the same time, press the lower part toward the center console so the lower edge hooks under the padded part of the side wall.

3. The ProClip mount is in place.

4. The ProClip mount is in place.