

Manual, Assembly instruction: Brodit 855481

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the grooved edge on the lower part of the ProClip over the frame surrounding the air vent.
2. Press the upper part of the ProClip downward and forward.
3. Hook the angled edge on the upper part of the ProClip under the frame surrounding the air vent.
4. The ProClip is in place.