

Manual, Assembly instruction: Brodit 855486

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent and the surrounding frame, to widen the gap.
2. Press the lower edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press down on top of the ProClip. Hook the upper part of the ProClip into the gap between the air vent and the surrounding frame.
4. The ProClip is in place.