

Manual, Assembly instruction: Brodit 855487

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the bottom edge of the mount on the frame surrounding the air vent.
2. Press down and all the way forward on the top of the mount, so the upper edge hooks/clips under the frame surrounding the air vent.
3. Press upward on the upper part of the mount to ensure it is hooked properly on to the frame
4. The ProClip mount is in place.