

Manual, Assembly instruction: Brodit 855489

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the air vent, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed, Peel off the adhesive tape covers on the ProClip.

2. Hook the S-shaped edge on the upper part of the ProClip into the gap next to the gap opener.

3. Press the ProClip downward and forward so the upper edge hooks under the frame surrounding the air vent. Press the lower part of the ProClip, with adhesive tape, into the gap between the dashboard and the control panel. Pull out the gap opener.

4. The ProClip in place.