

Manual, Assembly instruction: Brodit 855492

Center mount, High

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin edge on the upper part of the ProClip into the gap between the frame around the display and the dashboard.
2. Press the upper edge of the ProClip downward/forward, at the same time press/rotate the lower part of the ProClip downward so the upper edge hooks under the frame around the display.
3. Place your fingers behind the face plate of the ProClip and pull/flex so the lower edge hooks under the dashboard edge.
4. The ProClip is in place.