

Manual, Assembly instruction: Brodit 855493

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the grooved edge on the upper part of the ProClip under the frame surrounding the air vent.
2. Press the lower part of the ProClip upward/forward and hook the grooved lower edge over the frame surrounding the air vent.
3. This ProClip can be installed anywhere within the width of the air vents.
4. The ProClip is in place.