

Manual, Assembly instruction: Brodit 855497

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Hold the ProClip so the face plate is facing towards the steering wheel. Insert the J-shaped hook on the ProClip into the vent in the dashboard.

2. Pull the ProClip slightly toward the steering wheel so the J-shaped hook is properly in place.

3. Press downward on the ProClip so the edge snaps into place over the silver trim next to the steering wheel.

4. The ProClip is in place.