

Manual, Assembly instruction: Brodit 855498

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the grooved edge on the upper part of the ProClip under the frame surrounding the control panel.

2. Press the lower part of the ProClip upward/forward. Hook the grooved lower edge of the ProClip into the gap between the frame surrounding the air vent and the control panel.

3. This ProClip can be attached by the left air vent. A device installed in this position may block the display.

4. The ProClip is in place.