

Manual, Assembly instruction: Brodit 855499

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts: Part 1. Attaching part (the smallest part) Part 2. ProClip face plate.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard overhang, to widen the gap. Peel off the adhesive tape cover on Part 1, press the angled edge of Part 1 into the gap next to the gap opener. Press Part 1 upward and forward so the angled edge hooks behind the control panel. Pull out the gap opener.

2. Peel off the adhesive tape cover on Part 2. Hold Part 1 in the correct position, press it upward. At the same time, place Part 2 over the holes in Part 1 so the holes match.

3. Hold part 1 in the correct position, press it upward. At the same time, attach Part 2 onto Part 1 with the enclosed screws.

4. The ProClip is in place.