

Manual, Assembly instruction: Brodit 855505

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the panel above the buttons and the padded dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the thin lower edge of the ProClip into the gap next to the gap opener.

2. Pull the top of the ProClip upward and over the padded dashboard.

3. Press forward on the ProClip until the thin front edge goes into the gap between the display and the padded dashboard. Pull out the gap opener.

4. The ProClip is in place.