# Manual, Assembly instruction: Brodit 855506

Center mount

1.)

2.)

3.)

4.)

**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**1.** Use the enlcosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin edge of the enclosed gap opener into the seam between the panel surrounding the climate controls and the panel surrounding the hazard button, to widen the gap. Peel off the adhesive tape cover on the ProClip.

**2.** Insert the lower edge of the ProClip into the seam next to the gap opener. Hold the ProClip all the way into the seam and rotate it upward.

**3.** Remove the gap opener and insert it into the seam between the panel surrounding the hazard button and the air vent panel. Lift the top of the ProClip and insert the top edge into the seam next to the gap opener. Pull out the gap opener.

**4.** The ProClip is in place.