

Manual, Assembly instruction: Brodit 855507

Center mount NOT for models with JBL stereo.



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts Part 1. Attaching part Part 2. Face plate

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on Part 1. Press the thin lower edge on Part 1 into the gap between the trim and the dashboard. Press downward so the thin edge goes all the way into the gap and the adhesive tape attaches onto the dashboard.

2. Peel off the adhesive tape cover on Part 2. Place Part 2 above Part 1. Slide Part 2 downward so the holes match the holes in Part 1 and the right part with adhesive tape hooks behind the display.

3. Attach Part 2 onto Part 1 with the enclosed screws.

4. The ProClip is in place.