

Manual, Assembly instruction: Brodit 855514

Angled mount ONLY for models with factory navigation.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the control panel, to widen the gap.

2. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Press/Flip the ProClip forward and upward so the angled lower edge goes all the way into the gap and hooks behind the control panel. Pull out the gap opener.

3. Hook the angled edge on the upper part of the ProClip into the gap between the panel and the frame surrounding the buttons. Press down on top of the ProClip so the angled edge goes all the way into the gap.

4. The ProClip is in place.