

## Manual, Assembly instruction: Brodit 855529

Center mount ONLY for models with a padded dash panel under the center vent area.

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the plastic trim, to widen the gap. Insert the lower edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.
2. Press the gap opener into the gap between the dashboard and the air vent. Pull/Flex the ProClip upward and forward. Hook the top angled edge into the gap next to the gap opener.
3. Press down on the top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.