

Manual, Assembly instruction: Brodit 855530

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin edge of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press the gap into the gap between the frame surrounding the air vent and the dashboard. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener.

3. Press upward on the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. ProClip is in place.