

Manual, Assembly instruction: Brodit 855531

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the upper edge of the ProClip under the frame surrounding the air vent.
2. Press the ProClip upward and forward and hook the grooved lower edge over the frame surrounding the air vent.
3. This ProClip can also be placed on the left air vent.
4. The ProClip is in place.