

Manual, Assembly instruction: Brodit 855533

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin edge of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Press the curved edge on the left side of the ProClip into the gap between the center console panel frame and the padded part of the dashboard.

2. Flip the ProClip to the right so the curved edge on the left side of the ProClip hooks behind the center console panel frame. 3 Press firmly forward on the right side of the ProClip so the grooved edge goes into the gap below the gap opener. Press until you see or hear/feel it click into place. Pull out the gap opener.

4. The ProClip is in place.