

Manual, Assembly instruction: Brodit 855535

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the curved upper edge of the ProClip to the right of the air vent. Press the left edge of the angled upper curved edge into the gap between the frame surrounding the control panel and the dashboard.

2. Press/slide the ProClip leftward so all of the angled upper curved edge hooks behind the frame surrounding the control panel.

3. Press the thin end of the gap opener into the gap between the frame surrounding the air vent and the control panel, and keep it in the gap. Hook the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

4. ProClip is in place.