

Manual, Assembly instruction: Brodit 855536

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin edge of the enclosed gap opener into the gap between the panel sections to the left of the display, to widen the gap. Press one corner of the lower part of the ProClip into the gap next to the gap opener.
2. Press the rest of the lower edge all the way into the gap. Pull out the gap opener.
3. Press the gap opener into the gap between the dashboard and the panel frame surrounding the display. Lift the upper edge of the ProClip into the gap next to the gap opener. Press down on top of the ProClip so the edge goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.