

Manual, Assembly instruction: Brodit 855539

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the right edge of the ProClip into the gap in the sidewall of the center console.
2. Put your fingers under the left edge of the ProClip. Lift the left edge of the ProClip over the edge of the center console.
3. Press on the ProClip so the adhesive tape attaches properly.
4. The ProClip is in place.