

Manual, Assembly instruction: Brodit 855541

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the lower and the center sections of the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip.

2. Press the thin lower edge of the ProClip into the gap next to the gap opener. Flip the upper part of the ProClip upward/forward so the lower edge hooks behind the lower section of the dashboard. Pull out the gap opener.

3. Press the gap opener into the gap between the trim and the upper section of the dashboard. Press the thin upper edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.