

Manual, Assembly instruction: Brodit 855543

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the top of the ProClip all the way into the vent opening until the tab on the top of the ProClip rests against the dashboard.

2. Press the ProClip upward/forward and hook the grooved lower edge over the lower edge of the air vent.

3. The ProClip is in place.

4. The ProClip is in place.