

Manual, Assembly instruction: Brodit 855548

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts Part 1. Attaching part Part 2. Face plate

1. Part 1. Press the thin lower edge on Part 1 into the gap between the trim and the dashboard. Press downward so the thin edge goes all the way into the gap.

2. Fold up the mounting plate against the dashboard.

3. Attach Part 2 onto Part 1 with the enclosed screws.

4. The ProClip is in place.