

Manual, Assembly instruction: Brodit 855554

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the upper edge of the ProClip under the frame surrounding the air vent.
2. Press the lower part of the ProClip upward/forward and hook the grooved lower edge over the frame surrounding the air vent.
3. This ProClip can also be placed on the right air vent.
4. The ProClip is in place.