

Manual, Assembly instruction: Brodit 855555

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the lower edge of the ProClip into the gap in the center console side wall, below the knee pad.
2. Gently rotate the ProClip toward the drivers side, at the same time keep the lower edge in the gap so it hooks into place.
3. Pull the ProClip upwards over the console edge (be careful to avoid scratching the console). Snap the upper edge of the ProClip into the gap between the center console and the surrounding frame.
4. The ProClip is in place.