

Manual, Assembly instruction: Brodit 855557

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the angled edge on the upper part of the ProClip upward into the gap between the frame surrounding the stereo and the center console.
2. Slide the ProClip rightwards.
3. Hook the angled edge on the lower part of the ProClip into the gap between the frame surrounding the compartment and the dashboard.
4. The ProClip is in place.