

Manual, Assembly instruction: Brodit 855558

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the upper part of the ProClip under the dashboard overhang.

2. Press the ProClip upward/forward.

3. Hook the angled edge on the lower part of the ProClip into the gap between the air vent and the surrounding frame. Press on the ProClip so the adhesive tapes attach properly.

4. The ProClip is in place.