

Manual, Assembly instruction: Brodit 855560

Angled mount, High



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of the adhesive tape on the ProClip. Hook the notched edge on the left part of the ProClip onto the frame surrounding the air vent.
2. Press the ProClip leftward. Press the right part of the ProClip into the air vent and hook the notched edge onto frame surrounding the air vent.
3. This ProClip can also be placed on the right side of the center console.
4. The ProClip is in place