

Manual, Assembly instruction: Brodit 855576

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the grooved edge on the upper part of the ProClip under the frame surrounding the air vent.
2. Press forward on the lower part of the ProClip and hook the grooved edge over the frame surrounding the air vent.
3. Press on the ProClip so the adhesive tape attaches properly.
4. The ProClip is in place.