

Manual, Assembly instruction: Brodit 855577

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the grooved edge on the upper part of the ProClip under the frame surrounding the air vent.
2. Press the lower part of the ProClip upward/forward. Hook the grooved edge on the lower part of the ProClip over the frame surrounding the air vent.
3. This ProClip can also be placed onto the left air vent. A device in this position may block the display.
4. The ProClip is in place.