

Manual, Assembly instruction: Brodit 855580

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the upper part of the ProClip into the gap between the panel surrounding the air vents and the trim.
2. Pull the lower part of the ProClip downward and hook the angled edge under the panel surrounding the air vents.
3. Press upward on the lower part of the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.