

Manual, Assembly instruction: Brodit 855583

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip.

2. Press a corner of the angled upper edge of the ProClip into the gap between the frame surrounding the air vent and the dashboard. Then press down on the upper part so all of the angled edge goes into the gap.

3. Press down/forward on the lower part of the ProClip so the angled edge goes into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.