

Manual, Assembly instruction: Brodit 855584

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin ends of the enclosed gap openers into the gap between the frame surrounding the instrument panel and the dashboard, to widen the gap. Place them about 10 cm apart. Peel off the adhesive tape cover on the ProClip. Press the thin edge on the left part of the ProClip into the gap between the gap openers. Pull out the gap openers.

2. Press one of the gap openers into the gap between the air vent and the center console surrounding the display.

3. Press forward on the right side of the ProClip so the edge hooks into the gap above the gap opener. Pull out the gap opener.

4. The ProClip is in place.