

Manual, Assembly instruction: Brodit 855585

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the display and the center console panel, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.
2. Hook the lower edge of the ProClip under the right console side wall.
3. Press the ProClip leftward until the thin left edge goes into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.