

## Manual, Assembly instruction: Brodit 855595

Angled mount



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Place the upper part of the ProClip under the dashboard overhang.
2. Press the lower part of the ProClip upward/forward. Hook the angled lower edge over the frame surrounding the air vent.
3. This ProClip can be placed anywhere within the width of the air vent, as well as on the left side of the steering wheel. Do not place the ProClip so an installed device will block the display.
4. The ProClip is in place.