

Manual, Assembly instruction: Brodit 855596

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console frame and sidewall, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.
2. Hook the angled edge on the right side of the ProClip over the center console frame.
3. Press the ProClip forward until the angled left edge goes into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.