

Manual, Assembly instruction: Brodit 855599

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the display and the trim, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the thin edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
2. Press the upper part of the ProClip downward and forward so the upper edge, with adhesive tape, reaches the air vent. Carefully release the pressure so the upper part of the ProClip is pressed upward toward the dashboard overhang.
3. Press the ProClip forward/upward so the adhesive tape attaches properly.
4. The ProClip is in place.