

Manual, Assembly instruction: Brodit 855603

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Hook the grooved upper edge of the ProClip under the frame surrounding the air vent.
2. Press forward on the lower part of the ProClip and hook the angled lower edge over the frame surrounding the air vent.
3. This ProClip can also be attached onto the air vent on the right side of the center console.
4. The ProClip is in place.