

Manual, Assembly instruction: Brodit 855606

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the angled edge on the upper part of the ProClip behind the upper right corner of the frame surrounding the center console. Slide the ProClip sideways in the gap, toward the steering wheel, so it is placed over the air vent.

2. Hook the angled edge on the lower part of the ProClip under the frame surrounding the air vent.

3. Press upward on the lower part of the ProClip so the angled edge goes all the way into the gap.

4. The ProClip is in place.